





RMSE
Rework System
Ref.: RMSE-9QJ 100V
RMSE-1QJ 120V
RMSE-2QJ 230V

SPARE PARTS	
DDE CONTROL UNIT:	
-REAR CIRCUIT	0035389
-ENCLOSURE	
· TOP	0019028
· BOTTOM	0014567
· FRONT+DISPLAY	0036257
· BACK	0033173
MSE-B:	
- CIRCUIT	0033215
- ENCLOSURE	
· TOP	0032092
· BOTTOM	0032089
· FRONT	0032096
· BACK	0032091
- PUMP	0031985
- AC ADAPTER	0028084

Ref.: DDE-9D 100V FUSE T-2,5A
DDE-1D 120V FUSE T-2,5A
DDE-2D 230V FUSE T-2,5A



SPARE PARTS	
JTSE CONTROL UNIT:	
-ENCLOSURES:	
· TOP	0019028
· BOTTOM	0013486
· FRONT	0026199
· BACK	0021065
FOR REF. JTSE-9UA/JTSE-1UA:	
-CIRCUIT	0024361
-SUCTION PUMP	0026338
-HOT AIR PUMP	0018769
FOR REF. JTSE-2UA:	
-CIRCUIT	0024360
-SUCTION PUMP	0026337
-HOT AIR PUMP	0018769

Ref.: JTSE-9A 100V FUSE T-8A
JTSE-1A 120V FUSE T-8A
JTSE-2A 230V FUSE T-4A




DDE CONTROL UNIT


JTSE CONTROL UNIT







- Ø 0,85 - 0025114 (x2)
- Ø 0,55 - 0025112 (x2)
- Ø 0,4 - 0901512 (x2)




- Ø 0,84 - 0025121 (x2)
- Ø 0,61 - 0025119 (x2)
- Ø 0,51 - 0861540 (x2)



- Ø 10 - 0940110 (x2)
- Ø 7 - 0940111 (x2)
- Ø 4.3 - 0940112 (x2)




- 0014107 (230V)
- 0014105 (100V, 120V)
- JT-T2A (230V)
- JT-T1A (100V, 120V)





SCH-A




MSE-B




0024228




MS20




MS10



0786640




S7034 (x2)




AD-SF

0010433




DR-SF


0010433



JT-SF



CC1001



CC1001



CL6210 (x2)